



Berlebach®

Zubehör:
Accessories:

Berlebach®

Qualität seit 1898



Autoscheibenstativ Car window mount



2-Wege-Neiger 552 mit Schnellkupplung
2-way-tilt head 552 with quick release system

32018

Berlebach®

Stativtechnik

Wolfgang Fleischer
Chemnitzer Str. 2

D-09619 Mulda/ Germany

☎: +49(0) 37320-1201/1209

☎: +49(0) 37320- 1202

✉: info@berlebach.de

🌐: www.berlebach.de




Sehr geehrter Kunde,

vielen Dank, daß Sie sich für den Kauf dieses original *Berlebach*® Autoscheibenstativs entschieden haben.

Um die Führung und das Gestänge Ihrer Autoscheibe zu schonen, sollten Sie bei der Montage des Scheibenstativs in folgender Reihenfolge vorgehen.

- 1.) Autoscheibe soweit öffnen, bis das Scheibenstativ auf der Tür aufsitzt ! (siehe Skizze)
- 2.) Scheibenstativ aufsetzen
- 3.) Scheibenstativ festdrehen
- 4.) Nun können Sie das Stativ benutzen, wir wünschen viel Erfolg und gute Fotos.

Ihr BerlebachTeam.



Dear Customer,

Thank you for choosing to purchase this original Berlebach® car window pod.

When mounting the window pod, please follow the steps in the sequence given below so as to avoid damage to the guide and linkage system of your car window:

- 1.) Open the window far enough to ensure that the pod is supported on the door!
- 2.) Position the window pod
- 3.) Screw the pod firmly into place
- 4.) Now you can use the window pod. We wish you lots of shooting opportunities and good photos.

Your BerlebachTeam.

